

# Floor Type Air-Conditioner MFZ-KA25VA MFZ-KA35VA MFZ-KA50VA

# **INSTALLATION MANUAL**



 This manual only describes the installation of indoor unit. When installing the outdoor unit, refer to the installation manual of outdoor unit.

# CONTENTS

1.	THE FOLLOWING SHOULD ALWAYS BE OBSERVED FOR		Deu
	SAFETY	2	
2.	INSTALLATION DIAGRAM & ACCESSORIES	2	Frar
3.	SELECTING THE INSTALLATION LOCATION	3	
4.	INDOOR UNIT INSTALLATION	4	Ned
5.	INDOOR/OUTDOOR UNIT CONNECTION FINISHING AND		
	TEST RUN	9	Espa
6.	FOR MOVEMENT AND MAINTENANCE	1	



English

tsch

Русский

# FOR INSTALLER

# 1. THE FOLLOWING SHOULD ALWAYS BE OBSERVED FOR SAFETY

- Please provide an exclusive circuit for the air conditioner and do not connect other electrical appliances to it.
- Be sure to read "THE FOLLOWING SHOULD ALWAYS BE OBSERVED FOR SAFETY" before installing the air conditioner.
- · Be sure to observe the cautions specified here as they include important items related to safety.
- The indications and meanings are as follows.
- $\triangle$  Warning: Could lead to death, serious injury, etc.
- ⚠ Caution: Could lead to serious injury in particular environments when operated incorrectly.
- After reading this manual, be sure to keep it together with the instruction manual in a handy place on the customer's site.

# **A Warning**

- Do not install it by yourself (customer). Incomplete installation could cause injury due to fire, electric shock, the unit falling or leakage of water. Consult the dealer from whom you purchased the unit or special installer.
- Install the unit securely in a place which can bear the weight of the unit. When installed in an insufficient strong place, the unit could fall causing injury.
- Use the specified wires to connect the indoor and outdoor units securely and attach the wires firmly to the terminal block connecting sections so the stress of the wires is not applied to the sections. Incomplete connecting and fixing could cause a fire.
- Do not use intermediate connection of the power cord or the extension cord and do not connect many devices to one AC outlet. It could cause a fire or an electric shock due to defective contact, defective insulation, exceeding the permissible current, etc.
- Check that the refrigerant gas does not leak after installation has completed. If refrigerant gas leaks indoors, and comes into contrativity the fire of the head of the head of the second second

contact with the fire of a fan heater, space heater, stove, etc., harmful substances will be generated.

Perform the installation securely referring to the installation manual.

Incomplete installation could cause a personal injury due to fire, electric shock, the unit falling or leakage of water.

Perform electrical work according to the installation manual and be sure to use an exclusive circuit.

If the capacity of the power circuit is insufficient or there is incomplete electrical work, it could result in a fire or an electric shock.

Attach the electrical part cover to the indoor unit and the service panel to the outdoor unit securely.

If the electrical part cover in the indoor unit and/ or the service panel in the outdoor unit are not attached securely, it could result in a fire or an electric shock due to dust, water, etc.

Be sure to use the part provided or specified parts for the installation work.

The use of defective parts could cause an injury or leakage of water due to a fire, an electric shock, the unit falling, etc.

- Be sure to cut off the main power in case of setting up the indoor electronic control P.C. board or wiring works. It could cause an electric shock.
- The appliance shall be installed in accordance with national wiring regulations.
- When installing or relocating the unit, make sure that no substance other than the specified refrigerant (R410A) enters the refrigerant circuit.

Any presence of foreign substance such as air can cause abnormal pressure rise or an explosion.

# **▲** Caution

Earth the unit.

Do not connect the earth to a gas pipe, water pipe, lightning rod or telephone earth. Defective earthing could cause an electric shock.

- Do not install the unit in a place where an inflammable gas leaks. If gas leak and accumulate in the area surrounding the unit, it could cause an explosion.
- Install an earth leakage breaker depending on the installation place (Where it is humid). If an earth leakage breaker is not installed, it could cause an electric shock.
- Perform the drainage/piping work securely according to the installation manual. If there is a defect in the drainage/piping work, water could drop from the unit and household goods could be wet and damaged.
- Fasten a flare nut with a torque wrench as specified in this manual.

When fastened too tight, a flare nut may broken after a long period and cause a leakage of re-frigerant.



# 2. INSTALLATION DIAGRAM & ACCESSORIES

### ACCESSORIES

Check the following parts before installation.

<ind< th=""><th>loor unit&gt;</th><th></th><th></th><th></th></ind<>	loor unit>			
0	Drain hose	1		(4 core 1 5 mm <sup>2</sup> )
0	Remote controller holder	1	B	Extension nine
8	Fixing screw for (2) 3.5 × 16 mm (Black)	2	a	Wall hole sleeve
4	Pipe cover	1	Ŏ	Wall hole cover
6	Band	2		Pipe fixing band
6	Battery (AAA) for remote controller	2	e	(The quantity depends on the pipe length.)
0	Indoor unit mounting bracket	1		Fixing screw for $\textcircled{1}{1}$ 4 × 20 mm (The quantity
8	Fixing screw for $\bigcirc$ 4 × 25 mm	5	G	depends on the pipe length.)
9	Wood screw for the indoor unit fixation	4	G	Piping tape
0	Washer of	4	0	Putty
0	Felt tape (Used for left or left-rear piping)	1		Drain hose (or soft PVC. hose, 15 mm inner dia.
Ø	Wireless remote controller	1		or hard PVC pipe VP16)
ß	Air cleaning filter	1	0	Refrigeration oil

# FLARED CONNECTIONS

- This unit has flared connections on both indoor and outdoor sides.
- Refrigerant pipes are used to connect the indoor and outdoor units as shown in the figure below.
- Insulate both refrigerant and drain piping completely to prevent condensation.

### PIPING PREPARATION

(1) Table below shows the specifications of pipes commercially available.

Pipe	Outsid	e diameter	Insulation thickness	Insulation material
For liquid	6.3	35 mm	8 mm	Heat registing fear plactic
For goo	KA25/35	9.52 mm	8 mm	
Forgas	KA50	12.7 mm	8 mm	0.045 specific gravity

PART TO BE PROVIDED AT YOUR SIDE

Optional extension pipe

Use a copper pipe or a copper-alloy seamless pipe with a thickness of 0.8 mm (for ø6.35 and ø9.52) or 1.0 mm (for ø12.7). Never use any pipe with a thickness less than 0.8 mm (for ø6.35 and ø9.52) or 1.0 mm (for ø12.7), as the pressure resistance is insufficient.

O Ensure that the 2 refrigerant pipes are well insulated to prevent condensation.

③ Refrigerant pipe bending radius must be 100 mm or more.

#### ▲ Caution:

Be sure to use the insulation of specified thickness. Excessive thickness may cause incorrect installation of the indoor unit and lack of thickness may cause dew drippage.

# 3-1 INDOOR UNIT

1

1

1

1

2 to 5

2 to 5

1

1

1 or 2

1

- Where airflow is not blocked.
- Where cool air spreads over the entire room
- Maximum refrigerant piping length between indoor unit and outdoor unit is 20 m (for 25/35) 30 m (for 50) and the difference of height of both units is 12 m (for 25/35) 15 m (for 50).
- Rigid wall without vibration.
- Where it is not exposed to direct sunshine.
- Where easily drained.
- At a distance 1 m or more away from your TV and radio. Operation of the air conditioner may interfere with radio or TV reception in areas where reception is weak. An amplifier may be required for the affected device.
- In a place as far away as possible from fluorescent and incandescent lights (so the infrared remote control can operate the air conditioner normally).
- Where the air filter can be removed and replaced easily.

# 3-2 WIRELESS REMOTE CONTROLLER MOUNTING

- Place of mounting
  - Where it is easy to operate and easily visible.
  - Where children cannot touch.
- Mounting

Select a position about 1.2 m above the floor, check that signals from the controller are surely received by the indoor unit from that position ('beep' or 'beep-beep' receiving tone sounds), attach remote controller holder () to a pillar or wall, then set the wireless remote controller ().

In rooms where inverter type fluorescent lamps are used, the signal from the wireless remote controller may not be received.

# 4-1 INDOOR UNIT MOUNTING BRACKET INSTALLATION

- Install the bracket firmly to the wall structure (stud, etc.).
- Use a level to install the mounting bracket horizontally.
- Install the indoor unit 150 mm or below from the floor.



# 4-2 INDOOR UNIT PREPARATION

- Press the 2 positions indicated by the arrows is and open the front grille.
- Open the front grille and remove the two screws.
- Open the horizontal vane for the upper air outlet, push the top of the front panel in three locations, and then pull the top of the grille away from the indoor unit.
- Lift up the front grille to remove it.





# 4-3 INDOOR UNIT INSTALLATION

- Hook the top of the indoor unit on the indoor unit mounting bracket ().
- Use the included wood screws ④ and washer ⑥, and fasten the indoor unit at 2 locations(⇒) each at the top and the middle of the unit.



# 4-4 CONNECTING WIRE SPECIFICATIONS

· Use special room air conditioning circuit.

Indoor/outdoor unit connecting	Cable 4-core 1.5 mm <sup>2</sup> , in conformity
wire Specification	with Design 245 IEC 57.

A Warning:

Never cut the indoor and outdoor unit connecting wire and connect it to other wires. It may cause a fire.

## 4-5 INDOOR AND OUTDOOR CONNECTING WIRE CONNECTION

You can connect indoor/outdoor lead wire without removing the front panel.

- ① Open the front panel.
- ② Remove two screws holding the cabinet, then remove the cabinet.
- $\textcircled{\sc 3}$  Remove one screw holding the electrical cover, then remove the cover.
- ④ Remove one screw holding the cord clamp, then remove the clamp.
- (5) Pass the indoor/outdoor unit connecting wire and fix the wire to the terminal block.
- <sup>®</sup> Secure the indoor/outdoor unit connecting wire and the earth wire with the cord clamp.
- ⑦ Re-install the fixture and electrical cover securely.



Indoor/outdoor unit connecting wire (A)

A Warning:

- Use the indoor/outdoor unit connecting wire that meets the Standards to connect the indoor and outdoor units and fix the wire to the terminal block securely so that no external force is conveyed to the connecting section of the terminal block. Incomplete connection or fixing of the wire could result in a fire.
- Attach the cord clamp securely. If it is attached incorrectly, it could result in a fire or an electric shock due to dust, water, etc.



#### **△** Caution:

- · Be careful not to make mis-wiring.
- · Firmly tighten the terminal screws to prevent them from loosening.
- After tightening, pull the wires lightly to confirm that they do not move.
- If the connecting wire is incorrectly connected to the terminal block, the unit does not operate normally.
- · If an earth is incorrect, it may cause an electric shock.
- · Make earth wire a little longer than the others. (more than 55 mm)

### 4-6 AUTO RESTART FUNCTION

- These models are equipped with an auto restart function. If you do not want to use this function, please
  consult the service representative because the setting of the unit needs to be changed.
- When the indoor unit is controlled with the remote controller, the operation mode, the set temperature, and the fan speed are memorized by the indoor electronic control P.C. board. The auto restart function sets to work the moment the power has restored after power failure, then, the unit will restart automatically. If the unit is operated in "AUTO" mode before power failure, the operation mode (COOL, DRY or HEAT) is not stored in the memory. When the main power is turned on, the unit decides the operation mode by the initial room temperature at restart and starts operation again.

#### Operation

(1) If the main power has been cut, the operation settings remain.

② When three minutes have passed after power was restored, the unit will restart automatically according to the memory.

#### Notes:

- The operation settings are memorized when 10 seconds have passed after the remote controller was operated.
- If the main power is turned off or a power failure occurs while AUTO START/STOP timer is active, the timer setting is cancelled. As these models are equipped with an auto restart function, the air conditioner starts operating with timer cancelled at the same time that power is restored.
- If the unit has been off with the remote controller before power failure, the auto restart function does not work as the power button of the remote controller is off.
- To prevent breaker off due to the rush of starting current, systematize other home appliances not to turn on at the same time.

## 4-7 MAKING HOLES IN THE WALL AND FLOOR

#### MAKING HOLES

① Make ø65 mm holes (ø75 mm for KA50) that are approximately 5–7 mm deep and angled slightly downward outward from the room.

O Insert the wall hole sleeves O into the holes.



#### **▲** Caution:

Be sure to use the wall hole sleeves **(**). Otherwise, the indoor/outdoor unit connecting wires may contact a metal object in the wall or, in the case of hollow walls, small rodents may gnaw on the wires, resulting in a very dangerous situation.

FOR LEFT PIPING

09 6

#### **DETERMINING HOLE POSITIONS**

• The areas where the piping can be routed are indicated with oblique lines in the figure.

#### FOR REAR OR LEFT-REAR PIPING

(The following figure is a front view of the indoor unit installation location.)

FOR RIGHT DOWNWARD OR LEFT DOWNWARD PIPING

(The following figure is a view of the bottom of the indoor unit from above.)





FOR RIGHT PIPING

60

# 4-8 PIPING INSTALLATION

#### CONNECTING PIPE INSTALLATION

• Install the connecting pipes so that the piping can move slightly to the front, back, left, and right.



FOR RIGHT DOWNWARD PIPING





- Be sure to insulate the connecting pipes and place them near the rear of the indoor unit so that they do not contact the front panel.
- Be careful not to crush the connecting pipes when bending them.

• Use putty or a caulking compound to seal the holes.

#### FOR LEFT OR LEFT-REAR PIPING

Bundle the connecting pipes and drain hose together, and then wrap them in felt tape (2)



Cut and use the lower side panels on the left and right sides of the indoor unit as shown below. Smooth the cut edges of the side panels so that they will not damage the insulation coating.



## 4-9 EMBEDDING THE INDOOR UNIT IN A WALL

- When installing a grating, use a grating with narrow upper and lower horizontal bars so that the airflow from the upper and lower air outlets does not contact the bars. If the horizontal bars will block the lower air outlet, use a stand, etc., to adjust the height of the indoor unit. If the upper or lower air outlet is blocked, the air conditioner will not be able to cool or warm the room well.
- Do not block the receiver with the grating. Otherwise, the grating will interfere with the remote controller signal and significantly reduce the distance and area (angle) from which the signals can be received.
- Use a grating with vertical bars, etc., that has at least 75% open area. If the grating has horizontal bars or if the open area is less than 75%, performance could be reduced.
- When the indoor unit is embedded in a wall (built-in), the time it takes for the room temperature to reach the set temperature will increase.



#### EMBEDDED INDOOR UNIT SETTING (MUST BE PERFORMED)

- When embedding the indoor unit in a wall, restrict the movement of the horizontal vane for the upper air outlet so that it only operates horizontally.
- If this setting is not performed, heat will build up in the wall and the room will not be cooled or warmed properly.
- Cut the wires on the left and right sides of JRFBL using a pair of nippers, etc., as shown below.
   Control board



Cut the JRFBL wires

Cut the wires on both ends

### 4-10 DRAIN PIPING

• Be sure to route the drain piping slightly downward so that the drain water flows easily. (Fig. 1) Do not route the drain piping as shown in Fig. 2 to 5.





- If the drain hose provided with the indoor unit is too short, connect it with drain hose 1 that should be provided at your site. (Fig.6)
- When connecting the drain hose to the hard vinyl chloride pipe, be sure to insert it securely into the pipe. (Fig.7)
- If the indoor unit is installed in a high location such as a high-rise apartment, strong winds may cause the drain water to flow back through the drain hose and leak from the unit. If necessary, contact your nearest Mitsubishi Electric representative for the optional parts to prevent this problem.
- If the drain hose is routed indoors, be sure to wrap it in commercially-available insulation.
- If embedding the piping in a wall, remove the lower side panels on the left and right sides of the indoor unit when connecting the drain hose.
- Do not connect the drain piping directly to a septic tank, sewage tank, etc., where ammonia gases or hydrogen sulfide are produced.
- If there is slack in the drain hose or the end of the drain hose is raised up, the drain water may not flow smoothly and some drain water may collect in the hose. This can lead to a strange sound (burbling) being produced during strong winds or when a ventilation fan, etc., is used in a residence that is well-sealed. If necessary, contact your nearest Mitsubishi Electric representative for the optional parts to prevent this problem.

• When routing the drain piping, make sure that the drain hose () is routed as shown. (Fig. 8)

 Insert the drain hose all the way to the base of the drain pan. (Fig. 9) Make sure that the drain hose is securely caught on the projection in the hole in the drain pan.



- Route the drain hose diagonally below the connecting pipes.
- Make sure that the drain hose is not routed upward and that there are no waves in the hose.
- Do not pull the drain hose, and then wrap tape around it.
- Route the piping so that it does not project past the rear of the indoor unit. (Refer to the figure to the right.)

## 4-11 FRONT PANEL INSTALLATION

① Open the horizontal vane for the upper air outlet.

② Fit the front panel onto the indoor unit from the front, and then push the upper and lower areas that are marked with arrows.

Refrigerant

pipina

Push

Drain hose

Piping bent

outward

③ Push the areas below the upper air outlet and the areas above and below the lower air outlet that are marked with arrows.

④ After installing the front panel, install the 2 screws below the upper air outlet.

![](_page_7_Picture_23.jpeg)

# INSTALLATION INFORMATION FOR THE AIR CONDITIONER WITH R410A REFRIGERANT

- This room air conditioner adopts an HFC refrigerant (R410A) which will never destroy the ozone layer.
- Pay particular attention to the following points, though the basic installation procedure is same as that for R22 air conditioners.
- ① As R410A has a working pressure approx. 1.6 times as high as that of R22, some special tools and piping parts / materials are required. (Refer to the table below.)
- ② Take sufficient care not to allow water and other contaminations to enter the R410A refrigerant during storage and installation, since it is more susceptible to contaminations than R22.
- ③ For refrigerant piping, use clean, pressure-proof parts / materials specifically designed for R410A.
- (4) Composition change may occur in R410A since it is a mixed refrigerant. When charging, charge liquid refrigerant to prevent composition change.

## 5-1 TOOLS DEDICATED FOR THE AIR CONDITIONER WITH R410A RE-FRIGERANT

The following tools are required for R410A refrigerant. Some R22 tools can be substituted for R410A tools. The diameter of the service port on the stop valve in outdoor unit has been changed to prevent any other refrigerant being charged into the unit. (Cap size has been changed from 7/16 UNF with 20 threads to 1/2 UNF with 20 threads.)

R410A tools	Can R22 tools be used?	Description
		R410A has high pressures beyond the measurement range of existing
Gauge manifold	No	gauges.
Cauge marinolu	NO	Port diameters have been changed to prevent any other refrigerant from
		being charged into the unit.
Charge bose	No	Hose material and cap size have been changed to improve the pressure
Charge hose	NO	resistance.
Gas leak detector	No	Dedicated for HFC refrigerant.
Torque wrench	Yes	1/4 and 3/8
Elara tool	Yee	Clamp bar hole has been enlarged to reinforce the spring strength in the
	ies	tool.
Flare gauge	New	Provided for flaring work (to be used with R22 flare tool).
	Now	Provided to prevent the back flow of oil. This adapter enables you to use
vacuum pump auaptor	New	existing vacuum pumps.
Electronic scale for re-	Now	It is difficult to measure R410A with a charging cylinder because the refrig-
frigerant charging	INGM	erant bubbles due to high pressure and high-speed vaporization.

No: Not substitutable for R410A Yes: Substitutable for R410A

# 5-2 FLARING WORK

• Main cause of gas leakage is defect in flaring work. Carry out correct flaring work in the following procedure.

#### 1. Pipe cutting

• Cut the copper pipe correctly with pipe cutter.

#### 2. Burrs removal

- Completely remove all burrs from the cut cross section of pipe.
- Put the end of the copper pipe to downward direction as you remove burrs in order to avoid to let burrs drop in the piping.

![](_page_8_Figure_19.jpeg)

Spare reame

ine cutte

### 3. Putting nut on

- Remove flare nuts attached to indoor and outdoor units, then put them on pipe having completed burr removal. (not possible to put them on after flaring work)
- Flare nut for R410A pipe differs from R22 pipe. Refer to the following table for detail.

mm	R410A
ø6.35	17
ø9.52	22
ø12.7	26

#### 4. Flaring work

· Carry out flaring work using flaring tool as shown below.

![](_page_8_Figure_26.jpeg)

		A (mm)	
Outside	Flare tool for	Conventior	nal flare tool
diameter	R410A clutch type	Clutch type	Wing nut type
ø6.35 mm	0 to 0.5	1.0 to 1.5	1.5 to 2.0
ø9.52 mm	0 to 0.5	1.0 to 1.5	1.5 to 2.0
ø12.7 mm	0 to 0.5	1.0 to 1.5	1.5 to 2.0

• Firmly hold copper pipe in a die in the dimension shown in the table above.

#### 5. Check

- Compare the flared work with figure below.
- If flare is noted to be defective, cut off the flared section and do flaring work again.

![](_page_8_Figure_32.jpeg)

![](_page_8_Picture_33.jpeg)

# 5-3 PIPE CONNECTION

#### Note:

Fasten a flare nut with a torque wrench as specified in the table below. When fastened too tight, a flare nut may broken after a long period and cause a leakage of refrigerant.

#### 1. Indoor unit connection

Connect both liquid and gas pipings to indoor unit.

- Apply a thin coat of refrigeration oil I on the seat surface of pipe.
- For connection first align the center, then tighten the first 3 to 4 turns of flare nut.
- Use tightening torque table below as a guideline for indoor unit side union joint section, and tighten using two wrenches. Excessive tightening damages the flare section.

Pipe diameter	Tightening torque	
mm	N⋅m	kgf⋅cm
ø6.35	13.7 to 17.7	140 to 180
ø9.52	34.3 to 41.2	350 to 420
ø12.7	49.0 to 56.4	500 to 575

![](_page_9_Figure_9.jpeg)

#### 2. Outdoor unit connection

Connect pipes to stop valve pipe joint of the outdoor unit in the same manner applied for indoor unit.

• For tightening, use a torque wrench or spanner and use the same tightening torque applied for indoor unit.

#### **INSULATION AND TAPING**

① Cover piping joints with pipe cover.

② For outdoor unit side, surely insulate every piping including valves.

- ③ Using piping tape **⑤**, apply taping starting from the entry of outdoor unit.
- Stop the end of piping tape **(** with tape (with adhesive agent attached).
- When piping have to be arranged through above ceiling, closet or where the temperature and humidity are high, wind additional commercially sold insulation for prevention of condensation.

# 5-4 TEST RUN

- Before performing the test run, recheck for any wrong wiring.
   Wrong wiring prevents normal operation or results in blown fuse disabling operation.
- The test run can be started by pressing EMERGENCY OPERATION switch. When the EMERGENCY OP-ERATION switch is once pressed, the unit will start the test run (continuous operation) for 30 minutes. A thermostat does not work during this time. After 30 minutes the unit will start the EMERGENCY OPERA-TION at a fixed temperature setting of 24 °C in COOL MODE.
- Perform test run in the following procedure.
- Press the EMERGENCY OPERATION switch.

#### Note:

Three seconds after the EMERGENCY OPERATION switch is pressed, the auto front panel starts moving forward. Close the front panel before it starts moving.

① Press it once, and after test run for 30 minutes the EMERGENCY COOL MODE starts.

If the left side lamp of the operation indicator blinks every 0.5 seconds, inspect the indoor/outdoor unit connecting wire (a) for mis-wiring.

② Press it once more, and the EMERGENCY HEAT MODE starts.

③ Press it once more, and the operation stops.

(The operation mode changes in order of 1 ~ 3 every time the EMERGENCY OPERATION switch is pressed.)

![](_page_9_Picture_31.jpeg)

#### Note:

In starting the heating operation, indoor unit fan may not operate to prevent blowing cool air. Please wait for a few minutes until the temperature of heat exchanger rises and warm air blows out.

#### Checking the remote (infrared) signal reception

Press the ON/OFF button on the remote controller and check that an electronic sound is heard from the indoor unit. Press the ON/OFF button again to turn the air conditioner off.

If the indoor unit is operated with the remote controller, both the test run and the emergency operation are released by commands from the remote controller.

• Once the compressor stops, the restart preventive device operates so the compressor will not operate for three minutes to protect the air conditioner.

# 6. FOR MOVEMENT AND MAINTENANCE

# 5-5 CHECKING AFTER INSTALLATION

After finishing the installation, check the following items and mark the \_ next to each item

- □ Is the specified power supply voltage used?
- $\Box$  Is the power line equipped with the circuit breaker?
- □ Have the ends of the indoor/outdoor connecting wire been properly inserted into the terminal blocks?
- ☐ Has the indoor/outdoor connecting wire been secured firmly?
- □ Are the power supply cord and indoor/outdoor connecting wire connected directly to the units (no intermediate connections)?
- □ Is the earth wire longer than the other wires so that it will not become disconnected when tension is applied? □ Is the earth wire connected properly?
- Are the pipes designed for use with R410A or do they have the specified thickness?
- ☐ Has the leak test been carried out for the pipe connections?
- $\square$  Has air purging been carried out?
- ☐ Are the stop valves open fully?
- $\Box$  Is the drain hose properly installed?
- ☐ Has water been poured through the drain hose to confirm proper drainage?
- Are the pipes at the rear of the unit bundled with felt tape (for left and left-rear piping only)?
- Can the installation location bear the weight of the unit and not amplify its vibration or noise?
- □ Is the area under the unit free of objects that block the air outlet?
- □ Are the vertical and horizontal vanes closed securely?
- $\Box$  Is the front panel installed securely?
- $\Box$  Has the test run been carried out?
- □ Has the drain work been performed properly and are there no bubbling sounds?
- □ Have all of the A WARNING and A CAUTION items in "1. THE FOLLOWING SHOULD ALWAYS BE OBSERVED FOR SAFETY" been checked?

### 5-6 EXPLANATION TO THE CUSTOMER

- Using the OPERATING INSTRUCTIONS, explain the following to the customer, how to control temperature, how to remove the air filters, how to remove or put the remote controller in the remote controller holder, how to clean, precautions for operation, etc.
- Recommend the customer to read the OPERATING INSTRUCTIONS carefully.

## 6-1 PUMPING DOWN

When relocating or disposing of the air conditioner, pump down the system following the procedure below so that no refrigerant is released into the atmosphere.

- Connect the gauge manifold valve to the service port of the stop valve on the gas pipe side of the outdoor unit.
- ② Fully close the stop valve on the liquid pipe side of the outdoor unit.
- ③ Close the stop valve on the gas pipe side of the outdoor unit almost completely so that it can be easily closed fully when the pressure gauge shows -0.101 MPa [Gauge] (0 kgf/cm<sup>2</sup>).
- ④ Start the test run operation in COOL MODE by pressing EMERGENCY OPERATION switch once.
- (5) Fully close the stop valve on the gas pipe side of the outdoor unit when the pressure gauge shows 0.05 to 0 MPa [Gauge] (approx. 0.5 to 0 kgf/cm<sup>2</sup>).
- 6 Stop the test run operation by pressing the EMERGENCY OPERATION switch twice.

This product is designed and intended for use in the residential, commercial and light-industrial environment.

The product at hand is based on the following EU regulations:

- Low Voltage Directive 73/23/ EEC
- Electromagnetic Compatibility Directive 89/ 336/ EEC

![](_page_11_Picture_4.jpeg)

SG79Y506H03