

Interface (Cased) PAC-IF011B-E

INSTALLATION MANUAL

For safe and correct use, read this manual and the outdoor unit installation manual thoroughly before installing the interface unit.

INSTALLATIONSHANDBUCH

Lesen Sie zum sicheren und korrekten Gebrauch vor Installation der Anlage diese Anleitung sorgfältig durch.

MANUEL D'INSTALLATION

Pour une utilisation sûre et adaptée, lisez attentivement ce manuel avant d'installer l'unité d'interface.

INSTALLATIEHANDLEIDING

Lees deze handleiding grondig door voordat u het interface-apparaat installeert. Dan bent u verzekerd van een veilig en correct gebruik.

MANUAL DE INSTALACIÓN

Para una utilización segura y correcta del producto, lea este manual detenidamente antes de instalar la unidad de interfaz.

MANUALE DI INSTALLAZIONE

Per la sicurezza e il corretto utilizzo, leggere attentamente il presente manuale prima di installare l'unità interna.

ΕΓΧΕΙΡΙΔΙΟ ΟΔΗΓΙΩΝ ΕΓΚΑΤΑΣΤΑΣΗΣ

Για ασφαλή και σωστή χρήση, διαβάστε καλά αυτό το εγχειρίδιο πριν την εγκατάσταση της μονάδας διασύνδεσης.

MANUAL DE INSTALAÇÃO

Para uma utilização segura e correcta, leia este manual na íntegra antes de instalar a unidade de interface.

INSTALLATIONSMANUAL

Læs af sikkerhedshensyn denne vejledning grundigt, før De monterer interfaceenheden.

INSTALLATIONSMANUAL

För säker och korrekt användning bör du nogrannt läsa igenom denna handbok innan du installerar gränssnittsenheten.

MONTAJ ELKİTABI

Güvenli ve doğru kullanım için arabirim ünitesini monte etmeden önce bu kılavuzu dikkatli bir şekilde okuyun.

РУКОВОДСТВО ПО УСТАНОВКЕ

Для безопасного и правильного использования перед установкой интерфейсного блока внимательно прочитайте данное руководство.

POUR L'INSTALLATEUR

FOR INSTALLER

FÜR INSTALLATEURE

VOOR DE INSTALLATEUR

PARA EL INSTALADOR

PER L'INSTALLATORE

PARA O INSTALADOR

TIL INSTALLATØREN

FÖR INSTALLATÖREN

MONTÖR İÇİN

ДЛЯ УСТАНОВИТЕЛЯ

Español

Italiano

English

Deutsch

Français

Nederlands

Ελληνικά

Português

Dansk

Svenska

Türkçe

Русский

Contents

- S. Electrical work

 Note (Marking for WEEE)
 This symbol mark is for EU countries only.

 This symbol mark is according to the directive 2002/96/EC Article 10 Information for users and Annex IV.

 Your MITSUBISHI ELECTRIC product is designed and manufactured with high quality materials and components which can be recycled and reused.

 This symbol means that electrical and electronic equipment, at their end-of-life, should be disposed of separately from your household waste.

 Please, dispose of this equipment at your local community waste collection/recycling centre.

 In the European Union there are separate collection systems for used electrical and electronic product.

 Please, help us to conserve the environment we live in!

1. Safety precautions

 Before installing the interface unit, make sure you read all the "Safety precautions". Please report to your supply authority or obtain their consent before connecting this equipment to the power supply system. 	After installation, perform the test run to ensure normal operation. Then explain your customer the "Safety Precautions," use, and maintenance of the unit based on the information in the Operation Manual provided by local application manufacture. Both the Installation Manual and the Operation Manual must be given to the user.
▲ Warning: Precautions that must be observed to prevent injuries or death.	I nese manuals must always be kept by the actual users.
Δ Caution: Precautions that must be observed to prevent damages to the unit.	$\underline{\wedge}$ Warning: Carefully read the labels attached to the unit.

🕂 Warning:

- The unit must not be installed by the user. Ask an installer or an authorized technician to install the unit. If the unit is installed improperly, electric shock, or fire may be caused.
- For installation work, follow the instructions in the Installation Manual and use tools and pipe components specifically made for use with refrigerant specified in the outdoor unit installation manual.
- The unit must be installed according to the instructions in order to minimize the risk of damages by earthquakes, typhoons, or strong winds. Improperly installed unit may fall down and cause damages or injuries.
- The unit must be securely installed on a structure that can sustain its weight. If the unit is mounted on an unstable structure, it may fall down and cause damages or injuries.
- All electric work must be performed by a qualified technician according to local regulations and the instructions given in this manual. The unit must be powered by dedicated power lines and the correct voltage and circuit breakers must be used. Power lines with insufficient capacity or incorrect electrical work may result in electric shock or fire.

1.1. Before installation (Environment)

▲ Caution:

- Do not install the interface unit in outdoor location as it is designed for indoor installation only. Otherwise electric shock or breakdown may be caused by water drop, wind or dust.
- Do not use the unit in an unusual environment. If the interface unit is installed or exposed to steam, volatile oil (including machine oil), or sulfuric gas, or exposed to briny air, the internal parts can be damaged.
- Do not install the unit where combustible gases may leak, be produced, flow, or accumulate. If combustible gas accumulates around the unit, it may cause fire or explosion.

1.2. Before installation or relocation

- Be fully careful when moving the units. Do not hold the packaging bands.
 Wear protective gloves to unpack and to move it, in order to avoid your hands be injured by parts.
- When installing the unit in a hospital or in a building where communications equipment are installed, you may need to take measure to noise and electronic interference. Inverters, home appliances, high-frequency medical equipment, and radio communications equipment can cause the interface unit to malfunction or to breakdown. At the same time, the noise and electric interference from the interface unit may disturb the proper operation of medical equipment, and communications equipment.

Only the specified cables can be used for wiring. Connections must be

made securely without tension on the terminals. If cables are connected or

Terminal block cover panel of the unit must be firmly fixed. If the cover

panel is mounted improperly, dust and moisture may enter the unit, and it

Make sure to use accessories authorized by Mitsubishi Electric and ask

an installer or an authorized technician to install them. If accessories are

Do not remodel the unit. Consult an installer for repairs. If alterations or

The user should never attempt to repair the unit or transfer it to another

location. If the unit is installed improperly, it may cause electric shock or

fire. If the interface unit needs to be repaired or moved, ask an installer or

repairs are not performed correctly, it may cause electric shock or fire.

installed improperly, It may result in overheating or fire.

improperly installed, it may cause electric shock, or fire.

may cause electric shock or fire.

an authorized technician.

- Be sure to safely dispose of the packaging materials. Packaging materials, such as nails and other metal or wooden parts may cause injuries.
- Do not wash the interface unit. You may receive an electric shock.

1.3. Before electric work

▲ Caution:

- Be sure to install a circuit breaker. If it is not installed, there may be a risk to get an electric shock.
- For the power lines, use standard cables of sufficient capacity. Otherwise, it may cause a short circuit, overheating, or fire.
- When installing the power lines, do not apply tension to the cables. The cables may be cut or overheated resulting in a fire.
- Make sure to ground the unit. Do not connect the ground wire to gas or water pipes, lightning rods, or telephone grounding lines. If the unit is not properly grounded, there may be a risk to get an electric shock.
- Make sure to use circuit breakers (ground fault interrupter, isolating switch (+B fuse), and molded case circuit breaker) with the specified capacity. If the circuit breaker capacity is larger than the specified capacity, breakdown or fire may result.

1.4. Before starting the test run

- ▲ Caution:
- Turn on the main power switch of the outdoor unit more than 12 hours before starting operation. Starting operation immediately after turning on the power switch can severely damage the internal parts. Keep the main power switch turned on during the operation period.
- Before starting operation, check that all protective parts are correctly installed. Make sure not to get injured by touching high voltage parts.
- Do not touch any switch with wet hands. There may be a risk to get an electric shock.
- After stopping operation, make sure to wait at least 5 minutes before turning off the main power. Otherwise, it may cause breakdown.

2. Installing the interface unit



Fig. 2-1

2.1. Check the parts (Fig. 2-1)

The interface unit should be supplied with the following parts.

	Part Name	Q'ty
1	Interface unit	1
2	Thermistor	2

2.2. Choosing the interface unit installation location

- Do not install the interface unit in outdoor location as it is designed for indoor installation only. (It is not waterproof against raindrop.)
- Avoid locations where the unit is exposed to direct sunlight or other sources of heat.
- Select a location where easy wiring access to the power source is available.
- Avoid locations where combustible gases may leak, be produced, flow, or accumulate.
- Select a level location that can bear the weight and vibration of the unit.
- · Avoid locations where the unit is exposed to oil, steam, or sulfuric gas.

2.3. Installing the interface unit (Fig. 2-2, Photo.2-1)

- 1. Remove 2 screws from interface unit and remove the cover.
- 2. Install the 4 screws (locally supplied) in 4 holes. (a) Screw (b) Cover
 - © Hole for installation





3-ELECTRIC WIRE INLET When installed on a wall: Lower side

C

200 278



3.1.1. Interface unit power supplied from outdoor unit The following connection patterns are available.

The outdoor unit power supply patterns vary on models.





Photo.3-2

Interfac	e unit model	PAC-IF011B-E	
ing . × size m?)	Interface unit-Outdoor unit *		3× 1.5 (polar)
Wire No (m	Interface unit-Outdoor unit earth	*1	1 × Min.1.5
cuit ing	Interface unit-Outdoor unit S1-S2	*2	AC 230 V
Cir rat	Interface unit-Outdoor unit S2-S3	*2	DC24 V

*1. Max. 80 m

*2. The figures are NOT always against the ground.

S3 terminal has DC 24 V against S2 terminal. However between S3 and S1, these terminals are not electrically insulated by the transformer or other device.

- Notes: 1. Wiring size must comply with the applicable local and national code. 2. Power supply cables and interface unit/outdoor unit connecting cables shall not be lighter than polychloroprene sheathed flexible cable. (Design 60245 IEC 57)
 - 3. Install an earth longer than other cables.

3.1. Interface unit (Photo. 3-1)

- 1. Remove the cover.
- 2. Wire the power cable and control cable separately through the respective wiring inlets given in the photo.
- Do not allow slackening of the terminal screws.
 - (A) Inlet for control cable
 - B Inlet for power
 - Clamp D Interface / Outdoor unit connecting terminals
 - E Earth terminal

- Outdoor unit power supply А
- В Earth leakage breaker
- С Wiring circuit breaker or isolating switch
- D Outdoor unit
- Interface unit/outdoor unit connecting cables Е
- F Interface unit

3.1.2. Separate interface unit/outdoor unit power supplies

The following connection patterns are available.

The outdoor unit power supply patterns vary on models.





Photo.3-3

- Outdoor unit power supply А
- В Earth leakage breaker
- Wiring circuit breaker or isolating switch С
- Outdoor unit D
- F Interface unit/outdoor unit connecting cables
- F Interface unit
- G Interface unit power supply

If the interface and outdoor units have separate power supplies, refer to the table below.

	Separate power supply specifications
Interface unit controller connector (CNS2) connection change	Disconnected
Outdoor unit DIP switch settings (when using separate interface unit/outdoor unit power supplies only)	ON 3 OFF 1 2 Set the SW8-3 to ON. (SW8)

Interface unit model			PAC-IF011B-E		
Interfac	e unit power supply		~/N (Single Phase), 50 Hz, 230 V		
Interfac	e unit input capacity	*1	16 A		
Main sv	Main switch (Breaker)				
size	Interface unit power supply		2 × Min. 1.5		
ing ("x (Interface unit power supply earth		1 × Min. 1.5		
a Vir	Interface unit-Outdoor unit	*2	2 × Min. 0.3		
. Ni	Interface unit-Outdoor unit earth		-		
±	Interface unit L-N	*3	AC 230 V		
ating	Interface unit-Outdoor unit S1-S2	*3	-		
0 2	Interface unit-Outdoor unit S2-S3	*3	DC24 V		

*1. A breaker with at least 3.0mm contact separation in each pole shall be provided. Use non-fuse breaker (NF) or earth leakage breaker (NV).

*2 Max 120 m

*3. The figures are NOT always against the ground.

1. Wiring size must comply with the applicable local and national code. Notes:

- 2. Power supply cables and interface unit/outdoor unit connecting cables shall not be lighter than polychloroprene sheathed flexible cable. (Design 60245 IEC 57)
 - 3. Install an earth longer than other cables.

3.1.3. Connecting thermistor cable

Connect the thermistor 2 for the interface controller.

- 1. Target temp. thermistor (TH1)
- Connect the thermistor for the target temp. to 1 and 2 on the terminal block (TB61) on the interface controller.
- 2. Pipe temp. thermistor / Liquid (TH2)
- Connect the thermistor for the pipe temp. to 3 and 4 on the terminal block (TB61) on the interface controller.

Set the DIP switch 2-6 to ON of the interface controller.

When the thermistor cables are too long, cut it to the appropriate length. Do not bind it in the interface unit.

Caution:

Do not route the thermistor cables together with power cables. The sensor part of the thermistor should be installed where user must not touch.

(It is separated by the supplementary insulation from where user may touch.)



Photo.3-4

3.1.4. Connecting external input

Demand control is available by external input. It is possible to set the outdoor unit's power consumption by setting the switch of the interface controller.

Switch1, Switch 6 : Input selection of inverter capacity setting

Input	SW 1-1	SW 1-2	SW 1-3	SW 6-1	SW 6-2	Step for capacity setting
REMOTE SWITCH Type A (4bit-8 setting)	OFF	OFF	OFF	OFF	OFF	OFF/Step1/Step2//Step7/Auto step
REMOTE SWITCH Type B (1bit-1 setting)	ON	OFF	OFF	OFF	OFF	OFF/Step1/Step4/Step7/Auto step
4-20mA	ON	ON	OFF	ON	ON	OFF/Step1/Step2//Step7
1-5V	ON	ON	OFF	OFF	ON	OFF/Step1/Step2//Step7
0-10V	OFF	OFF	ON	OFF	OFF	OFF/Step1/Step2//Step7
0-10kΩ	ON	OFF	ON	OFF	OFF	OFF/Step1/Step2//Step7/Auto step
No input (AUTO mode)	OFF	ON	ON	OFF	OFF	Only Auto step mode

• REMOTE SWITCH Type A (4bit - 8 setting) / Type B (1bit -1 setting)

		21 (0/)!	,		0,			
TB142	TB142	TB142	TB142 Step f		o for capacity setting					Bomark
(COM-IN5)	(COM-IN6)	(COM-IN7)	(COM-IN8)	ТуреА			ТуреВ			Kennark
OFF	OFF	OFF	OFF	[OFF]	OFF	0%	[OFF]	OFF	0%	OFF
ON	OFF	OFF	OFF	[ON]	Step1	10%	[ON]	Step1	10%	
OFF	ON	OFF	OFF		Step2	20%		Step4	50%	
ON	ON	OFF	OFF		Step3	30%		1	Î	Fixed capacity
OFF	OFF	ON	OFF		Step4	50%		Step7	100%	mode
ON	OFF	ON	OFF		Step5	70%		Î	Î	mode
OFF	ON	ON	OFF		Step6	80%		1	Ť	
ON	ON	ON	OFF		Step7	100%		Î	Î	
OFF	OFF	OFF	ON		Auto ste	эp		Auto ste	р	Auto step mode
						attennes and			and the second	

I/F

TB142

At site 4 bit 8 switch OFF~AUTO step





TB142

Photo.3-5

Demand control is available by connecting remote switches with terminal No.10 - 14. Make sure to use the non-voltage switch (for the remote switch) Remote switch cable length : Maximum 10m

Remote switch : Minimum applicable load DC12V, 1mA

4-20mA / 1-5V / 0-10V / 0-10kΩ

①Use 4-20mA / 1-5V / 0-10V

Connect the transmission cables to No. 3 and 4 on the terminal block (TB62). No. 3 on the terminal block(TB62) : Plus side

No. 4 on the terminal block(TB62) : Minus side (Reference side) [®]Use adjustable resistor (0-10kΩ)

Connect the transmission cables to No. 1 and 2 on the terminal block (TB62).

						(-)
Adjustable resistor (0-10kΩ)	4-20mA	1-5V	0-10V	Ste cap set	p for acity ting	Remark
0~100Ω	4~5mA	0~1.25V	0~0.63V	OFF	0%	Stop
510Ω	7mA	1.75V	1.88V	Step1	10%	
1kΩ	9mA	2.25V	3.13V	Step2	20%]
2kΩ	11mA	2.75V	4.38V	Step3	30%	Fixed
3.3kΩ	13mA	3.25V	5.63V	Step4	50%	
4.3kΩ	15mA	3.75V	6.88V	Step5	70%	(112 lixed)
5.6kΩ	17mA	4.25V	8.13V	Step6	80%	
7.5kΩ	19~20mA	4.75~5V	9.38~10V	Step7	100%	
10kΩ	-	-	-	Auto st	ер	Auto step mode
OPEN(12k0~)	_	_	_	OFF	0%	Stop

*The value of the above-mentioned table becomes the center of the input value. Cable length : Maximum 10m

At site

I/F

External function setting

This function is setting operation mode or stopping compressor, by the external signal.						TB142
TB142	Item	OFF	ON	Remark	0-10 kΩ (<u>2</u>	1/⊢ [1]2]3]4]
1-2 (IN1)	Forced Comp. OFF	Normal	Forced Comp. OFF		4-20mA/1-5V/0-10V (3⊕	
3-4 (IN2)Item	Fixed operation mode	Cooling	Heating	Available when SW2-1 and SW2-2	Wired remote controller (At site
				are ON	(For maintenance)	
			1862			

Cable length : Maximum 10m

Remote switch : Minimum applicableload DC12V, 1mA

Caution:

The external input signals are separated by basic insulation from power supply for the unit.

The external input signals should be separated by supplementary insulation from where user may touch in case that it is installed where user may touch.

Connect the terminals by using the ring terminals and also insulate the cables of adjoining terminals when wiring to terminal block.

3. Electrical work

3.1.5. Connecting External Output

The signal in the following states can be output.						
TB141			Item	OFF	ON	
1-2	(OUT1)	X1	Operation Output	OFF	ON	
3-4	(OUT2)	X2	Error Output	Normal	Error	
5-6	(OUT3)	X3	Comp. Output	OFF(Comp. OFF)	ON	(Comp. ON)
7-8	(OUT4)	X4	Defrost Output	OFF	ON	(Defrosting)
9-10	(OUT5)	X5	Mode(Cool) Output	OFF	ON	(Cooling)
11-12	(OUT6)	X6	Mode(Heat) Output	OFF	ON	(Heating)
13-14	(OUT7)	-	_	-		-

Cable length : Maximum 50m

Output specification : Non-voltage switch 1A or less , 240V AC

*Connect the surge absorber according to the load at site.



Note : External output signals are separated by basic insulation from other circuit of interface.

Caution : When 2 or more external outputs are used, the power supply on the output side should be the same.

3.1.6. Wiring specification	n Externa	l output /	External	input
Locally supplied parts				

Item	Name	Model and specifications
External output function	External output signal wire	Use sheathed vinyl coated cord or cable.
		Wire type : CV, CVS or equivalent.
		Wire size : Stranded wire 0.5mm ² to 1.25mm ²
		Solid wire: ϕ 0.65mm to ϕ 1.2mm
	Display lamp, etc.	Non-voltage Contact AC220-240V (DC30V), 1A or less
External input function	External input signal wire	Use sheathed vinyl coated cord or cable.
		Wire type : CV, CVS or equivalent.
		Wire size : Stranded wire 0.5mm ² to 1.25mm ²
		Solid wire : ϕ 0.65mm to ϕ 1.2mm
	Switch	Non-voltage "a" contact

3.1.7. Switch setting It is possible to set the following function by setting the switch of the interface controller.

• SW2-1/2-2 : Fixed operation mode

SW2-1	SW2-2	Details
OFF	OFF	Not FIX (Depending on Remote controller setting)
ON	OFF	[Cooling]FIX
OFF	ON	[Heating]FIX
ON	ON	External input(Depending on TB142-3,4)

Setting temperature

 SW2-3/2-4/2-5 : Fixed set temperature [For Auto step mode only] 										
	SW2-3	SW2-4	SW2-5	Details						
	OFF	OFF	OFF	Not fixed (Remote controller setting)						
	ON	OFF	OFF	Cooling 19°C/Heating 17°C FIX						
	OFF	ON	OFF	20°C FIX						
	ON	ON	OFF	22°C FIX						
	OFF	OFF	ON	24°C FIX						
	ON	OFF	ON	26℃ FIX						
	OFF	ON	ON	28°C FIX						
	ON	ON	ON	Cooling 30°C / Heating 28°C FIX						

Set switches in case of auto step mode.

3.1.8.Before test run

After completing installation and the wiring and piping of the local application and outdoor units, check for refrigerant leakage, looseness in the power supply or control wiring, wrong polarity, and no disconnection of one phase in the supply.

Use a 500-volt megohmmeter to check that the resistance between the power supply terminals and ground is at least 1.0MΩ.

Warning:

Do not use the system if the insulation resistance is less than $1.0M\Omega$.

Caution:

Do not carry out this test on the control wiring (low voltage circuit) terminals.



Photo.3-6

TB141

Guide to plan local applications

* This interface is to connect Mr. Slim inverter outdoor unit of MITSUBISHI ELECTRIC to local applications. Be sure to check the following when planning local applications.

* MITSUBISHI ELECTRIC does not take any responsibility on the local system design.

1. Heat exchanger

(1) Withstanding pressure

Designed pressure of outdoor unit is 4.15 MPa. Following must be satisfied for burst pressure of connecting application. Burst pressure : More than 12.45 MPa (3 times more than designed pressure)

(2) Performance

Secure the heat exchanger capacity which meets the following conditions. If the conditions are not met, it may result in malfunction caused by the protection operation or the outdoor unit may be turned off due to the operation of protection system.

- 1. Evaporate temperature is more than 4°C in max. frequency operation under *1 the cooling rated conditions.
- 2. Condense temperature is less than 60°C in max. frequency operation under *2 the heating rated conditions.
- 3. In case of hot water supply, condense temperature is less than 58°C in max. frequency operation with the outside temperature 7°C D.B./6°C W.B.
 - *1. Indoor: 27°C D.B./19°C W.B. Outdoor: 35°C D.B./24°C W.B. *2. Indoor: 20°C D.B. Outdoor: 7°C D.B./6°C W.B.
- (3) Heat exchanger internal capacity

Heat exchanger internal capacity must be within the capacity range shown below. If the heat exchanger below the minimum capacity is connected, it may result in the back flow of liquid or the failure of the compressor.

If the heat exchanger above the maximum capacity is connected, it may result in the deficiency in performance due to lack of refrigerant or overheating of the compressor.

Minimum capacity : 10 × Model capacity [cm³] / Maximum capacity : 30 × Model capacity [cm³]

- e.g. When connecting to PUHZ-RP100 VHA2
 - Minimum capacity : $10 \times 100 = 1000 \text{ cm}^3$ Maximum capacity : $30 \times 100 = 3000 \text{ cm}^3$

Model capacity	35	50	60	71	100	125	140	200	250
Maximum capacity [cm ³]	1050	1500	1800	2130	3000	3750	4200	6000	7500
Minimum capacity [cm ³]	350	500	600	710	1000	1250	1400	2000	2500

(4) Contamination maintenance

- 1. Wash the inside of heat exchanger to keep it clean. Be sure to rince not to leave flux. Do not use chlorine detergent when washing.
- 2. Be sure that the amount of contamination per unit cubic content of heat transfer pipe is less than the following amount.
 - Example) In case of ϕ 9.52mm

Residual water : 0.6mg/m, Residual oil : 0.5mg/m, Solid foreign object : 1.8mg/m

2. Thermistor position

- <Target temp.thermistor(TH1)> (Used only in *auto step mode(Only for Air to Air applications))
 - 1. Put thermistor(TH1) where average intake temperature for heat exchanger can be detected.
 - 2. It is better to put thermistor(TH1) where radiant heat from heat exchanger can be avoided.
 - To use this interface for manual step control, put a fixed resistor of $4\sim 10k\Omega$ instead of thermistor(TH1 on the terminal block TB61).
 - * Auto step mode: In this mode, the capacity step of the outdoor unit is controlled automatically to let the target (intake) temperature reach the setting temperature.(Only for air to air application)

<Liquid pipe thermistor(TH2)>

- 1. Put thermistor(TH2) where liquid refrigerant pipe temperature can be detected.
- 2. It is better to protect the thermistor(TH2) with heat insulating materials not to be affected by the ambient temperature, etc.
- 3. In case that the refrigerant is distributed by distributor, put thermistor(TH2) before the distributor.

This product is designed and intended for use in the residential, commercial and light-industrial environment.

The product at hand is • based on the following • EU regulations:

- Low Voltage Directive 2006/95/EC
- Electromagnetic Compatibility Directive 2004/108/EC

Please be sure to put the contact address/telephone number on this manual before handing it to the customer.

