

Mr.SLIM

Air-Conditioners PLA-RP·AA

INSTALLATION MANUAL

FOR INSTALLER

安装人员适用

For safe and correct use, please read this installation manual thoroughly before installing the air-conditioner unit.



English

中文

Contents

1.	Safety precautions	2
2.	Installation location	3
3.	Installing the indoor unit	3
4.	Installing the pipes	5
5.	Refrigerant piping work	5

1. Safety precautions

- Before installing the unit, make sure you read all the "Safety precautions".
- Please report to your supply authority or obtain their consent before connecting this equipment to the power supply system.

A Warning:

Describes precautions that must be observed to prevent danger of injury or death to the user.

A Caution:

Describes precautions that must be observed to prevent damage to the unit.

After installation work has been completed, explain the "Safety Precautions," use, and maintenance of the unit to the customer according to the information in the Operation Manual and perform the test run to ensure normal operation. Both the Installation Manual and Operation Manual must be given to the user for keeping. These manuals must be passed on to subsequent users.

A Warning:

- Ask a dealer or an authorized technician to install the unit.
- For installation work, follow the instructions in the Installation Manual and use tools and pipe components specifically made for use with refrigerant specified in the outdoor unit installation manual.
- The unit must be installed according to the instructions in order to minimize the risk of damage from earthquakes, typhoons, or strong winds. An incorrectly installed unit may fall down and cause damage or injuries.
- The unit must be securely installed on a structure that can sustain its weight.
 If the air conditioner is installed in a small room measures must be taken to
- If the air conditioner is installed in a small room, measures must be taken to
 prevent the refrigerant concentration in the room from exceeding the safety
 limit in the event of refrigerant leakage. Should the refrigerant leak and cause
 the concentration limit to be exceeded, hazards due to lack of oxygen in the
 room may result.

1.1. Before installation (Euvironment)

▲ Caution:

- Do not use the unit in an unusual environment. If the air conditioner is installed in areas exposed to steam, volatile oil (including machine oil), or sulfuric gas, areas exposed to high salt content such as the seaside, the performance can be significantly reduced and the internal parts can be damaged.
- Do not install the unit where combustible gases may leak, be produced, flow, or accumulate. If combustible gas accumulates around the unit, fire or explosion may result.
- Do not keep food, plants, caged pets, artwork, or precision instruments in the direct airflow of the indoor unit or too close to the unit, as these items can be damaged by temperature changes or dripping water.

1.2. Before installation or relocation

▲ Caution:

- Be extremely careful when transporting the units. Two or more persons are needed to handle the unit, as it weighs 20 kg or more. Do not grasp the packaging bands. Wear protective gloves as you can injure your hands on the fins or other parts.
- Be sure to safely dispose of the packaging materials. Packaging materials, such as nails and other metal or wooden parts may cause stabs or other injuries.
- 1.3. Before electric work

▲ Caution:

- Be sure to install circuit breakers. If not installed, electric shock may result.
- For the power lines, use standard cables of sufficient capacity. Otherwise, a short circuit, overheating, or fire may result.
- When installing the power lines, do not apply tension to the cables.

1.4. Before starting the test run

▲ Caution:

- Turn on the main power switch more than 12 hours before starting operation. Starting operation just after turning on the power switch can severely damage the internal parts.
- Before starting operation, check that all panels, guards and other protective parts are correctly installed. Rotating, hot, or high voltage parts can cause injuries.

- 6. Drainage piping work
 6

 7. Electrical work
 6

 8. Test run
 9

 9. System controll
 11

 10. Installing the grille
 11
- S: Indicates an action that must be avoided.
- Indicates that important instructions must be followed.
- : Indicates a part which must be grounded.
- $\textcircled{\begin{tabular}{ll} \hline \end{tabular}}$: Indicates that caution should be taken with rotating parts.
- 2 : Indicates that the main switch must be turned off before servicing.
- : Beware of electric shock.
- : Beware of hot surface.
- ELV: At servicing, please shut down the power supply for both the Indoor and Outdoor Unit.

\land Warning:

Carefully read the labels affixed to the main unit.

- Ventilate the room if refrigerant leaks during operation. If refrigerant comes into contact with a flame, poisonous gases will be released.
- All electric work must be performed by a qualified technician according to local regulations and the instructions given in this manual.
- Use only specified cables for wiring.
- The terminal block cover panel of the unit must be firmly attached.
- Use only accessories authorized by Mitsubishi Electric and ask a dealer or an authorized technician to install them.
- The user should never attempt to repair the unit or transfer it to another location.
- After installation has been completed, check for refrigerant leaks. If refrigerant leaks into the room and comes into contact with the flame of a heater or portable cooking range, poisonous gases will be released.
- When the room humidity exceeds 80% or when the drainpipe is clogged, water may drip from the indoor unit. Do not install the indoor unit where such dripping can cause damage.
- When installing the unit in a hospital or communications office, be prepared for noise and electronic interference. Inverters, home appliances, high-frequency medical equipment, and radio communications equipment can cause the air conditioner to malfunction or breakdown. The air conditioner may also affect medical equipment, disturbing medical care, and communications equipment, harming the screen display quality.
- Thermal insulation of the refrigerant pipe is necessary to prevent condensation. If the refrigerant pipe is not properly insulated, condensation will be formed.
- Place thermal insulation on the pipes to prevent condensation. If the drainpipe is installed incorrectly, water leakage and damage to the ceiling, floor, furniture, or other possessions may result.
- Do not clean the air conditioner unit with water. Electric shock may result.
- Tighten all flare nuts to specification using a torque wrench. If tightened too much, the flare nut can break after an extended period.
- Be sure to ground the unit. If the unit is not properly grounded, electric shock may result.
- Use circuit breakers (ground fault interrupter, isolating switch (+B fuse), and molded case circuit breaker) with the specified capacity. If the circuit breaker capacity is larger than the specified capacity, breakdown or fire may result.
- Do not operate the air conditioner without the air filter set in place. If the air filter is not installed, dust may accumulate and breakdown may result.
- Do not touch any switch with wet hands. Electric shock may result.
- Do not touch the refrigerant pipes with bare hands during operation.
- After stopping operation, be sure to wait at least five minutes before turning off the main power switch. Otherwise, water leakage or breakdown may result.

2. Installation location

Refer to the outdoor unit installation manual.

3. Installing the indoor unit



Fig. 3-1





3.1. Check the indoor unit accessories (Fig. 3-1)

The indoor unit should be supplied with the following accessories.

	Accessory name	Q'ty
1	Installation template	1
2	Washers (with insulation)	4
	Washers (without insulation)	4
3	Pipe cover (for refrigerant piping joint)	
	small diameter	1
	large diameter	1
4	Band (large)	6
	Band (small)	2
5	Screw with washer (M5 \times 25) for mounting grille	4
6	Drain socket	1
7	Insulation	1

3.2. Ceiling openings and suspension bolt installation locations (Fig. 3-2)

Using the installation template (top of the package) and the gauge (supplied as an
accessory with the grille), make an opening in the ceiling so that the main unit can
be installed as shown in the diagram. (The method for using the template and the
gauge are shown.)

* Before using, check the dimensions of template and gauge, because they change due to fluctuations of temperature and humidity.

- * The dimensions of ceiling opening can be regulated within the range shown in following diagram; so center the main unit against the opening of ceiling, ensuring that the respective opposite sides on all sides of the clearance between them becomes identical.
- Use M10 (3/8") suspension bolts.
 - * Suspension bolts are to be procured at the field.
- Install securely, ensuring that there is no clearance between the ceiling panel & grille, and between the main unit & grille.
 - A Outer side of main unit
 - Bolt pitchCeiling opening
 - D Outer side of Grille
- Grille
- Grile
 Grile
 Ceiling
- © Multi function casement (option)

Entire periphery

* Note that the space between ceiling panel of the unit and ceiling slab and etc must be 10 to 15 mm.

		(mm)
Models	С	D
RP3	241	258
RP4,5,6	281	298

3. Installing the indoor unit







Fig. 3-4





3.3. Branch duct hole and fresh air intake hole (Fig. 3-3)

At the time of installation, use the duct holes (cut out) located at the positions shown in following diagram, as and when required.

• A fresh air intake hole for the optional multi function casement can also be made. Note:

The figure marked with * in the drawing represent the dimensions of the main unit excluding those of the optional multi function casement. When installing the optional multi function casement, add 135 mm to the di-

mensions marked on the figure.

When installing the branch ducts, be sure to insulate adequately. Otherwise condensation and dripping may occur. ① ø150 cut out hole

- A Branch duct hole B Indoor unit
- © Fresh air intake hole
- () ø175 burring hole pitch (K) Fresh air intake hole diagram

N ø100 cut out hole

O Ceiling

- Drain pipe
- ① 3-ø2.8 burring hole M ø125 burring hole pitch
- E Refrigerant pipe (F) Branch duct hole diagram (view from
- either side)
- G Cut out hole
- (H) 14-ø2.8 burring hole
- 3.4. Suspension structure (Give site of suspension strong structure) (Fig. 3-4)

• The ceiling work differs according to the construction of the building. Building constructors and interior decorators should be consulted for details.

- (1) Extent of ceiling removal: The ceiling must be kept completely horizontal and the ceiling foundation (framework: wooden slats and slat holders) must be reinforced in order to protect the ceiling from vibration.
- (2) Cut and remove the ceiling foundation.
- (3) Reinforce the ends of the ceiling foundation where it has been cut and add ceiling foundation for securing the ends of the ceiling board.
- (4) When installing the indoor unit on a slanting ceiling, attach a pillar between the ceiling and the grille and set so that the unit is installed horizontally.
- ① Wooden structures
- Use tie beams (single storied houses) or second floor beams (two story houses) as reinforcing members.
- Wooden beams for suspending air conditioners must be sturdy and their sides must be at least 6 cm long if the beams are separated by not more than 90 cm and their sides must be at least 9 cm long if the beams are separated by as much as 180 cm. The size of the suspension bolts should be ø10 (3/8"). (The bolts do not come with the unit.)

⑦ Ferro-concrete structures

Secure the suspension bolts using the method shown, or use steel or wooden hangers, etc. to install the suspension bolts.

3.5. Unit suspension procedures (Fig. 3-5)

Suspend the main unit as shown in the diagram. Figures given in parentheses represent the dimensions in case of installing optional multi function casement.

- 1. In advance, set the parts onto the suspension bolts in the order of the washers (with insulation), washers (without insulation) and nuts (double).
- · Fit the washer with cushion so that the insulation faces downward.
- · In case of using upper washers to suspend the main unit, the lower washers (with insulation) and nuts (double) are to be set later.
- 2. Lift the unit to the proper height of the suspension bolts to insert the mounting plate between washers and then fasten it securely.
- When the main unit can not be aligned against the mounting hole on the ceiling, it 3. is adjustable owing to a slot provided on the mounting plate.
- Make sure that step A is performed within 17-22 mm. Damage could result by failing to adhere to this range. (Fig. 3-6)

▲ Caution:

Use the top half of the box as a protective cover to prevent dust or debris from getting inside the unit prior to installation of the decorative cover or when applving ceiling materials.

3.6. Confirming the position of main unit and tightening the suspension bolts (Fig. 3-7)

- Using the gauge attached to the grille, ensure that the bottom of the main unit is properly aligned with the opening of the ceiling. Be sure to confirm this, otherwise condensation may form and drip due to air leakage etc.
- · Confirm that the main unit is horizontally levelled, using a level or a vinyl tube filled with water.
- After checking the position of the main unit, tighten the nuts of the suspension bolts securely to fasten the main unit.
- The installation template (top of the package) can be used as a protective sheet to prevent dust from entering the main unit when the grilles are left unattached for a while or when the ceiling materials are to be lined after installation of the unit is finished.
- * As for the details of fitting, refer to the instructions given on the Installation template.

4

A Main unit B Ceiling © Installation template (top of the

D Screw with washer (Accessory)

package)

4. Installing the pipes



Fig. 4-1

5. Refrigerant piping work





Fig. 5-1

A Flare cutting dimensions

Copper pipe O.D.	Flare dimensions
(mm)	øA dimensions (mm)
ø6.35	8.7 - 9.1
ø9.52	12.8 - 13.2
ø12.7	16.2 - 16.6
ø15.88	19.3 - 19.7



Fig. 5-2

4.1. Refrigerant and drainage piping locations of indoor unit

The figure marked with * in the drawing represent the dimensions of the main unit excluding those of the optional multi function casement. (Fig. 4-1)

- A Drain pipe
- B Ceiling
- © Grille
- D Refrigerant pipe (liquid) (E) Refrigerant pipe (gas)
- ③ Water supply inlet
- G Main unit
- · When the optional multi-functional casement is installed, add 135 mm to the dimensions marked on the figure.

5.1. Connecting pipes (Fig. 5-1)

- · When commercially available copper pipes are used, wrap liquid and gas pipes with commercially available insulation materials (heat-resistant to 100 °C or more, thickness of 12 mm or more).
- · The indoor parts of the drain pipe should be wrapped with polyethylene foam insulation materials (specific gravity of 0.03, thickness of 9 mm or more).
- Apply thin layer of refrigerant oil to pipe and joint seating surface before tightening flare nut.
- Use two wrenches to tighten piping connections.
- · Use refrigerant piping insulation provided to insulate indoor unit connections. Insulate carefully.

B Flare nut tightening torque

Copper pipe O.D.	Flare nut O.D.	Tightening torque
(mm)	(mm)	(N⋅m)
ø6.35	17	14 - 18
ø9.52	22	34 - 42
ø12.7	26	49 - 61
ø15.88	29	68 - 82
ø15.88	36	100 - 120

© Apply refrigerating machine oil over the entire flare seat surface. Œ

Use the flare	nuts as follows.
---------------	------------------

	RP3	RP4-6	
Indoor unit (Liquid)	Flare nut attached to	Flare nut attached to	
	indoor liquid valve	indoor liquid valve	
Indoor unit (Gas)	Flare nut attached to	* Flare nut in outdoor	
	indoor gas valve	unit accessories	
Outdoor unit (Liquid)	Flare nut attached to	Flare nut attached to	
	outdoor liquid valve	outdoor liquid valve	
Outdoor unit (Gas)	Flare nut attached to	Flare nut attached to	
	outdoor gas valve	outdoor gas valve	

* In case that the flare nut attached to indoor gas valve is used, gas leakage or even pipe extraction will occur.

5.2. Indoor unit (Fig. 5-2)

Heat insulation for refrigerant pipes:

- ① Wrap the enclosed large-sized pipe cover around the gas pipe, making sure that the end of the pipe cover touches the side of the unit.
- ② Wrap the enclosed small-sized pipe cover around the liquid pipe, making sure that the end of the pipe cover touches the side of the unit.
- ③ Secure both ends of each pipe cover with the enclosed bands. (Attach the bands 20 mm from the ends of the pipe cover.)
- · After connecting the refrigerant piping to the indoor unit, be sure to test the pipe connections for gas leakage with nitrogen gas. (Check that there is no refrigerant leakage from the refrigerant piping to the indoor unit.)

5.3. For twin/triple combination

Refer to the outdoor unit installation manual.

6. Drainage piping work



Fig. 6-1





7. Electrical work





6.1. Drainage piping work (Fig. 6-1)

- Use VP25 (O. D. ø32 PVC TUBE) for drain piping and provide 1/100 or more downward slope.
- Be sure to connect the piping joints using a polyvinyl type adhesive.
- · Observe the figure for piping work.
- Use the included drain hose to change the extraction direction.
- ① Correct piping
- ② Wrong piping
- (A) Insulation (9 mm or more)
- B Downward slope (1/100 or more) © Support metal
- (K) Air bleeder
- C Raised
- M Odor trap
- Grouped piping
- D O. D. ø32 PVC TUBE
- (E) Make it as large as possible
- E Indoor unit $\ensuremath{\textcircled{}}$ G Make the piping size large for grouped piping.
- Downward slope (1/100 or more)
 O. D. ø38 PVC TUBE for grouped piping.
- (9 mm or more insulation)

J Up to 85 cm

- 1. Connect the drain socket (supplied with the unit) to the drain port. (Fig. 6-2) (Affix the tube using PVC adhesive then secure it with a band.)
- 2. Install a locally purchased drain pipe (PVC pipe, O.D. ø32).
- (Affix the pipe using PVC adhesive then secure it with a band.)
- 3. Insulate the tube and pipe. (PVC pipe, O.D. ø32 and socket)
- 4. Check that drain flows smoothly.
- 5. Insulate the drain port with insulating material, then secure the material with a band. (Both insulating material and band are supplied with the unit.)
 - (A) Unit
 - B Insulating material
 - C Band (large)
 - Drain port (transparent)
 - (E) Insertion margin
 - (F) Matching
 - G Drain pipe (O.D. ø32 PVC TUBE)
 - (H) Insulating material (purchased locally)
 - ① Transparent PVC pipe
 - J O.D. ø32 PVC TUBE (Slope 1/100 or more)
 - (K) Band (small)
 - ① Drain socket

7.1. Indoor unit (Fig. 7-1)

- 1. Remove the two electrical wiring service panels.
- Wire the power cable and control cable separately through the respective wiring 2. entries given in the diagram.
- Do not allow slackening of the terminal screws Always install an earth, longer than other cables.
- (Earth cable dia: Thicker than 1.6 mm)
- Leave excess cable so that the electrical box can be suspended below the unit during servicing. (Approx. 50 to 100 mm)
 - A Entry for control cable
 - B Entry for power
 C Clamp
 - D Service panel for indoor controller switch setting
 - © Service panel for electrical wiring
 - Electric heater power supply terminals (PLH models)
 - © Indoor / Outdoor unit connecting terminals
 - (H) Remote controller connector
 - ① Secure with the clamp
 - Intake sensor
 - (K) Holder
- Selecting non-fuse breaker (NF) or earth leakage breaker (NV).

7. Electrical work











<510 100.1>	
SW contents Main	Remote controller Main/Sub setting
ON/OFF	Main/Sub
Comment	Set one of the two remote controllers at one group to "Main"
<sw 2="" no.=""></sw>	
SW contents Main	When remote controller power turned on
ON/OFF	Normally on/Timer mode on
Comment	When you want to return to the timer mode when the power is restored after a power failure when a Program timer is connected, select "Timer mode".
<sw 3="" no.=""></sw>	
SW contents Main	Cooling/heating display in AUTO mode
ON/OFF	Yes/No
Comment	When you do not want to display "Cooling" and "Heating" in the Auto mode, set to "No".
<sw 4="" no.=""></sw>	

Fig. 7-4

SW contents Main Intake temperature display ON/OFF Yes/No Comment When you do not want to display the intake temperature, set to "No".





Fig. 7-5

7.2. Remote controller

7.2.1. For wired remote controller

1) Installing procedures

- (1) Select an installing position for the remote controller. (Fig. 7-2)
- The temperature sensors are located on both remote controller and indoor unit.
- Procure the following parts locally:
- Two piece switch box
- Thin copper conduit tube
- Lock nuts and bushings
- A Remote controller profile
- B Required clearances surrounding the remote controller
- © Installation pitch (2) Seal the service entrance for the remote controller cord with putty to prevent pos-
- sible invasion of dew drops, water, cockroaches or worms. (Fig. 7-3)
- A For installation in the switch box:
- B For direct installation on the wall select one of the following:
- Prepare a hole through the wall to pass the remote controller cord (in order to run the remote controller cord from the back), then seal the hole with putty.
- Run the remote controller cord through the cut-out upper case, then seal the cut-out notch with putty similarly as above.
- B-1. To lead the remote controller cord from the back of the controller:
- B-2. To run the remote controller cord through the upper portion:
- (3) For direct installation on the wall
 - © Wall
 - D Conduit
 - E Lock nut
 - F Bushing
 - G Switch box
 - (H) Remote controller cord
 - ① Seal with putty
 - ① Wood screw

2) Connecting procedures (Fig. 7-4)

- Connect the remote controller cord to the terminal block.
 To TB5 on the indoor unit
 - B TB6 (No polarity)
- ② Set the dip switch No.1 shown below when using two remote controller's for the same group.

© Dip switches

Setting the dip switches

The dip switches are at the bottom of the remote controller. Remote controller Main/ Sub and other function settings are performed using these switches. Ordinarily, only change the Main/Sub setting of SW No.1. (The factory settings are all "ON".)

7.2.2. For wireless remote controller

1) Installation area

- · Area in which the remote controller is not exposed to direct sunshine.
- Area in which there is no nearby heating source.
- · Area in which the remote controller is not exposed to cold (or hot) winds.
- Area in which the remote controller can be operated easily.
- Area in which the remote controller is beyond the reach of children.

2) Installation method (Fig. 7-5)

- (1) Attach the remote controller holder to the desired location using two tapping screws.
- 2 Place the lower end of the controller into the holder.
 - Remote controller
 - B Wall
 - © Display panel
 - Display parts
 Display parts
 Display parts
- The signal can travel up to approximately 7 meters (in a straight line) within 45 degrees to both right and left of the center line of the receiver.

3) Setting (Fig. 7-6)

- ① Insert batteries.
- © Press the SET button with something sharp at the end.
- ③ Press the temp 🕐 🔊 button to set the Model No.
- Press the SET button with something sharp at the end.
- WORLEREN and Model No. are lighted for three seconds, then turned off.

Indoor	Outdoor	A Model No.
PLH, PCH, PKH-P·GAH	PUH	001
	PUH, PUHZ	001
FLA, FCA, FKA-F·GA	PU	033
PKH-P·FAH	PUH	003
	PUH	003
	PU	035

7. Electrical work







Fig. 7-8



Fig. 7-9

4) Assigning a remote controller to each unit (Fig. 7-7)

Each unit can be operated only by the assigned remote controller.

Make sure each pair of an indoor unit PC board and a remote controller is assigned to the same pair No.

- 5) Wireless remote controller pair number setting operation
- Press the SET button with something sharp at the end. Start this operation from the status of remote controller display turned off.
 MORE SEET blinks and Model No. is lighted.
- ② Press the _____ button twice continuously.
- Pair No. "0" blinks.
- ③ Press the temp O () button to set the pair number you want to set.
- ④ Press the SET button with something sharp at the end.
- Set pair number is lighted for three seconds then turned off.

A Pair No. of wireless remote controller	Indoor PC board
0	Factory setting
1	Cut J41
2	Cut J42
3~9	Cut J41, J42

7.3. Function settings

7.3.1. For wired remote controller (Fig. 7-8)

Changing the power voltage setting

· Be sure to change the power voltage setting depending on the voltage used.

 Go to the function setting mode. Switch OFF the remote controller. Press the (A) and (B) buttons simultaneously and hold to

Press the (a) and (b) buttons simultaneously and hold them for at least 2 seconds. FUNCTION will start to flash.

- O Use the O button to set the refrigerant address (\blacksquare) to 00.
- 3 Press 0 and [--] will start to flash in the unit number (\Bbb{N}) display.
- (4) Use the \mathbb{C} button to set the unit number (\mathbb{N}) to 00.
- S Press the E MODE button to designate the refrigerant address/unit number. [--] will flash in the mode number (I) display momentarily.
- ⑥ Press the ⑦ buttons to set the mode number (I) to 04.
- O Press the G button and the current set setting number (\amalg) will flash.

Use the $\ensuremath{\mathbb{F}}$ button to switch the setting number in response to the power supply voltage to be used.

Power supply voltage

220 V, 230 V : setting number = 2

- (8) Press the MODE button (E) and mode and the setting number (I) and (II) will change to being on constantly and the contents of the setting can be confirmed.
- ③ Press the FILTER A and TEST RUN B buttons simultaneously for at least two seconds. The function selection screen will disappear momentarily and the air conditioner OFF display will appear.

7.3.2. For wireless remote controller (Fig. 7-9) Changing the power voltage setting

Be sure to change the power voltage setting depending on the voltage used. Go to the function select mode

Press the $\begin{tabular}{c} \end{tabular}$ button $\begin{tabular}{c} \end{tabular}$ twice continuously.

(Start this operation from the status of remote controller display turned off.)

Press the temp () button © once to set "50". Direct the wireless remote controller

toward the receiver of the indoor unit and press the <u>button</u> (a). (c) Setting the unit number

Press the temp () (a) button () and () to set the unit number "00". Direct the wireless remote controller toward the receiver of the indoor unit and press the indoor (). (3) Selecting a mode

Enter 04 to change the power voltage setting using the O O and O O buttons. Direct the wireless remote controller toward the receiver of the indoor unit and press the $\overset{h}{\overset{h}{\longrightarrow}}$ button O.

Current setting number:

- 1 = 1 beep (one second)
 - 2 = 2 beeps (one second each)
 - 3 = 3 beeps (one second each)

④ Selecting the setting number

Use the O O and O O buttons to change the power voltage setting to 01 (240 V). Direct the wireless remote controller toward the sensor of the indoor unit and press the $\overset{h}{\overset{h}{\longrightarrow}}$ button O.

(5) To select multiple functions continuously

Repeat steps ③ and ④ to change multiple function settings continuously.

⑥ Complete function selection

Direct the wireless remote controller toward the sensor of the indoor unit and press the $(\widehat{\mathbb{Q}})$ button $\widehat{\mathbb{C}}$.

Note:

Whenever changes are made to the function settings after construction or maintenance, be sure to record the added functions with an "O", in the "Check" column provided on the chart.

Function table

Select unit number 00					
Mode	Settings	Mode no.	Setting no.	Initial setting	setting
Power failure automatic recovery	Not available	0.1	1	0	
	Available	1 01	2		
Indoor temperature detecting	Indoor unit operating average		1	0	
	Set by indoor unit's remote controller	02	2		
	Remote controller's internal sensor	1	3		
LOSSNAY connectivity	Not Supported		1	0	
	Supported (indoor unit is not equipped with outdoor-air intake)	03	2		
	Supported (indoor unit is equipped with outdoor-air intake)	1	3		
Power voltage	240 V	04	1		
_	220 V, 230 V	1 04	2	0	
Auto mode (only for PUHZ)	Energy saving cycle automatically enabled	05	1	0	
	Energy saving cycle automatically disabled	05	2		
Select unit numbers 01 to 03 or all units (AL [wired	d remote controller]/07 [wireless remote controller])		•		
Mode	Settings	Mode no.	Setting no.	Initial setting	setting
Filter sign	100Hr		1		
	2500Hr	07	2	0	
	No filter sign indicator	1	3		
Fan speed	Standard (PLH/PLA-P·AA(H)/PLA-RP·AA)/Silent (PLH/PLA-				
	P·KA(H), PCH/PCA)		'		
	High ceiling () (PLH/PLA-P·AA(H)/PLA-RP·AA)/Standard (PLH/	08	0		
	PLA-P·KA(H), PCH/PCA)		2		
	High ceiling (2) (PLH/PLA-P·AA(H)/PLA-RP·AA)/High ceiling		0		
	(PLH/PLA-P·KA(H), PCH/PCA)		3		
No. of air outlets	4 directions		1	0	
	3 directions	09	2		
	2 directions	1	3		
Installed options (high-performance filter)	Not supported	10	1	0	
	Supported	1 10	2		
Up/down vane setting	No vanes		1		
	Equipped with vanes (vanes angle setup ①)	11	2	0	
	Equipped with vanes (vanes angle setup 2)	1	3		
Energy saving air flow	Disabled	12	1	0	
(Heating mode)	Enabled	12	2		
0 Ta al man			1		

Test run 8.

8.1. Before test run

- After completing installation and the wiring and piping of the indoor and outdoor units, check for refrigerant leakage, looseness in the power supply or control wiring, wrong polarity, and no disconnection of one phase in the supply.
- ► Use a 500-volt megohmmeter to check that the resistance between the power supply terminals and ground is at least 1.0MΩ.









Do not carry out this test on the control wiring (low voltage circuit) terminals.

A Warning:

Do not use the air conditioner if the insulation resistance is less than 1.0M Ω . Insulation resistance

8.2. Test run

- The following 3 methods are available.
- 8.2.1. Using wired remote controller (Fig. 8-1)
- ① Turn on the power at least 12 hours before the test run.
- ② Press the [TEST] button twice. ➡ "TEST RUN" liquid crystal display
- ③ Press the [Mode selection] button. ➡ Make sure that wind is blown out.
- ④ Press the [Mode selection] button and switch to the cooling (or heating) mode. ➡ Make sure that cold (or warm) wind is blown out.
- ⑤ Press the [Fan speed] button. → Make sure that the wind speed is switched.
- ⑥ Switch the wind direction by pressing the [Airflow] or [Louver] button.
- ➡ Make sure that horizontal outlet, downward outlet, and other wind direction adjustments are possible.
- ➡ Check operation of the outdoor unit fan.
- (8) After the checks, always turn off the power.
- 8.2.2. Using wireless remote controller (Fig. 8-2)
- Turn on the power to the unit at least 12 hours before the test run.
 Press the button twice continuously.
- (Start this operation from the status of remote controller display turned off.) (A) [ESTRUM and current operation mode are displayed.
- ③ Press the MODE (\$ △ \$ \$) button to activate ∞∞L≎ mode, then check whether cool air is blown out from the unit.
- ④ Press the Mode (♠♦♣ ♥ ◘) button to activate HEAT ♥ mode, then check whether warm air is blown out from the unit.
- (5) Press the 5 button and check whether fan speed changes.
- 6 Press the state of the set of the set
- ⑦ Press the ON/OFF button to stop the test run.

Note:

- · Point the remote controller towards the indoor unit receiver while following steps (2) to (7).
- It is not possible to run the in FAN, DRY or AUTO mode.



B 00 10 TEST RU min •

Fig. 8-4

8.2.3. Using SW4 in outdoor unit

Refer to the outdoor unit installation manual.

8.3. Self-check

- 8.3.1. Wired remote controller (Fig. 8-3)
- (1) Turn on the power.
- Press the [CHECK] button twice.
- ③ Set refrigerant address with [TEMP] button if system control is used.
- ④ Press the [ON/OFF] button to stop the self-check.
 - CHECK button
 - B Refrigerant address
 - © TEMP. button
 - D IC: Indoor unit
 - OC: Outdoor unit
 - Check code
 - ③ Unit address

8.3.2. Wireless remote controller (Fig. 8-4)

- Turn on the power.
 Press the _____ button twice.
 - (Start this operation from the status of remote controller display turned off.) (A) CHECK begins to light.
- B «00» begins to blink.
- ③ While pointing the remote controller toward the unit's receiver, press the 'n button. The check code will be indicated by the number of times that the buzzer sounds from the receiver section and the number of blinks of the operation lamp.
- ④ Press the ON/OFF button to stop the self-check.

• For description of each check code, refer to the following table.

1 Check code	Symptom	② Buzzer sound	③ OPE LED
P1	Intake sensor error	Single beep × 1	Lit for 1 sec. × 1
P2	Pipe sensor error	Single beep × 2	Lit for 1 sec. × 2
P4	Drain sensor error	Single beep × 4	Lit for 1 sec. × 4
P5	Drain pump error	Single beep $\times 5$	Lit for 1 sec. × 5
P6	Freezing / Overheating safeguard operation	Single beep \times 6	Lit for 1 sec. \times 6
P8	Pipe temperature error	Single beep × 8	Lit for 1 sec. × 8
P9	TH5 sensor error	Single beep × 2	Lit for 1 sec. × 2
U0–UP	Outdoor unit error	Double beep \times 1	Lit for 0.4 sec. + 0.4 sec. \times 1
F1–FA	Outdoor unit error	Double beep \times 1	Lit for 0.4 sec. + 0.4 sec. \times 1
E0E5	Signal error between remote controller and indoor units	Sounds other than above	Lights other than above
E6–EF	Communication error between indoor and outdoor units	Sounds other than above	Lights other than above
	No alarm history	No sound	Not lit
FFFF	No unit	Triple beep	Not lit

· On wireless remote controller

② The continuous buzzer sounds from receiving section of indoor unit.

③ Blink of operation lamp

· On wired remote controller

① Check code displayed in the LCD.

• If the unit cannot be operated properly after the above test run has been performed, refer to the following table to remove the cause.

	Symptom	Cause	
Wired remote controller			LED 1, 2 (PCB in outdoor unit)
НО	For about 2 minutes following power-on	After LED 1, 2 are lighted, LED 2 is turned off, then only LED 1 is lighted. (Correct operation)	• For about 2 minutes following power-on, operation of the remote controller is not possible due to system start-up. (Correct operation)
$H0 \rightarrow Error \ code$	After about 2 minutes has expired following power-on	Only LED 1 is lighted. \rightarrow LED 1, 2 blink.	 Connector for the outdoor unit's protection device is not connected. Reverse or open phase wiring for the outdoor unit's power terminal block (L1, L2, L3)
Display messages do not apper even when operation switch is turned ON (operation lamp does not light up).		Only LED 1 is lighted. \rightarrow LED 1 blinks twice, LED 2 blinks once.	 Incorrect wiring between indoor and outdoor units (incorrect polarity of S1, S2, S3) Remote controller wire short

On the wireless remote controller with condition above, following phenomena takes place.

· No signals from the remote controller are accepted.

• OPE lamp is blinking.

• The buzzer makes a short pipng sound.

8. Test run

Note:

Operation is not possible for about 30 seconds after cancellation of function selection. (Correct operation)

For description of each LED (LED1, 2, 3) provided on the indoor controller, refer to the following table.

LED1 (power for microcomputer)	Indicates whether control power is supplied. Make sure that this LED is always lit.
LED2 (power for remote controller)	Indicates whether power is supplied to the remote controller. This LED lights only in the case of the indoor unit which is connected to the outdoor unit refrigerant address "0".
LED3 (communication between indoor and outdoor units)	Indicates state of communication between the indoor and outdoor units. Make sure that this LED is always blinking.



System controll 9.

Refer to the outdoor unit installation manual.

10. Installing the grille











Fig. 10-3





10.1. Checking the contents (Fig. 10-1)

• This kit contains this manual and the following parts.

	Accessory name	Q'ty	Remark
1	Grille	1	950 × 950 (mm)
2	Screw with captive washer	4	$M5 \times 0.8 \times 25$
3	Gauge	1	(Divided into four parts)
4	Fastener	2	
5	Screw	4	4×8
6	Wireless remote controller	1	for PLP-6AALM
7	Wired remote controller	1	for PLP-6AAM

10.2. Preparing to attach the grille (Fig. 10-2)

- With the gauge (3) supplied with this kit, adjust and check the positioning of the unit relative to the ceiling. If the unit is not properly positioned relative to the ceiling, it may allow air leaks or cause condensation to collect.
- Make sure that the opening in the ceiling is within the following tolerances: 860×860 - 910×910
- · Make sure that step A is performed within 17-22 mm. Damage could result by failing to adhere to this range.
 - A Main unit
 - B Ceiling
 - © Gauge ③ (inserted into the unit)
 - D Ceiling opening dimensions

10.2.1. Removing the intake grille (Fig. 10-3)

- Slide the levers in the direction indicated by the arrow (1) to open the intake grille. Unlatch the hook that secures the grille.
- Do not unlatch the hook for the intake grille.
- · With the intake grille in the "open" position, remove the hinge of the intake grille from the grille as indicated by the arrow ②

10.2.2. Removing the corner panel (Fig. 10-4)

- Remove the screw from the corner of the corner panel. Slide the corner panel as indicated by the arrow (1) to remove the corner panel.
 - (E) Hole for the grille's hook
 - E Corner panel
 - © Intake grille levers
- D Grille hook

A Intake grille

Grille

G Screw

Fig. 10-4

10. Installing the grille





Fig. 10-5

Á

A Main unit

③ Grille

G Hole A Hole B ① Bell shaped hole

washer 2. © Corner drain pipe area

(F) Screw with washer (2)

B

B Detailed diagram of installed screw with

D Screw with washer 2 (for temporary use)





- A Ceiling
- B Main unit
- © Grille
- D Make sure that there are no gaps.
- (E) Adjust the nut of the main unit using a wrench. etc

Fig. 10-7



Fig. 10-8

10.3. Selection of the air outlets

For this grille the discharge direction is available in 11 patterns. Also, by setting the Remote controller to the appropriate settings, you can adjust the air-flow and speed. Select the required settings from the Table according to the location in which you want to install the unit

- 1) Decide on the discharge direction pattern.
- 2) Be sure to set the remote contoller to the appropriate settings, according to the number of air outlets and the height of the ceiling on which the unit will be installed.

Note:

For 3 and 2-directional, please use the air outlet shutter plate (option).

10.4. Installing the grille

10.4.1. Preparations (Fig. 10-5)

· Install the two enclosed screws with washer ② in the main unit (at the corner drain pipe area and at the opposite corner) as shown in the diagram.

10.4.2. Temporary installation of the grille (Fig. 10-6)

- · Temporarily secure the grille using the bell shaped holes by aligning the corner drain pipe area of the main unit with the two holes of the grille that are marked A and B
 - Make sure that the lead wiring of the grille does not get pinched between the grille and the main unit.

10.4.3. Securing the grille (Fig. 10-7)

• Secure the grille to the main unit by tightening the previously installed two screws (with captive washer) as well as the two remaining screws (with captive washer). Make sure that there are no gaps between the main unit and the grille or the grille and the ceiling.

Fixing gaps between the grille and the ceiling

With the grille attached, adjust the height of the main unit to close the gap.

10.4.4. Wire connection (Fig. 10-8)

- · Be sure to connect the unit to the connector (white, 10-pole). Next, attach the white glass tube that comes with the main unit so that the tube covers the connector. Close the opening of the glass tube with the fastener.
- Make sure that there is no slack in the lead wire at the clamp of the main unit.

A Warning:

If the connector is not covered with the glass tube, tracking resulting in fire may occur.

10. Installing the grille







A Clamp
 B Cable

D Hole

E Screw

© Corner panel





10.5. Locking the up/down airflow direction (Fig. 10-9)

The vanes of the unit can be set and locked in up or down orientations depending upon the environment of use.

- Set according to the preference of the customer.
- The operation of the fixed up/down vanes and all automatic controls cannot be performed using the remote controller. In addition, the actual position of the vanes may differ from the position indicated on the remote controller.
- Turn off the main power switch.
- Injuries and or an electrical shock may occur while the fan of the unit is rotating. ② Disconnect the connector for the vane motor of the vent that you want to lock.
- (While pressing the button, remove the connector in the direction indicated by the arrow as shown in the diagram.) After removing the connector, insulate it with tape.

10.6. Installing the wireless sensor (Fig. 10-10)

- Pull out the wireless sensor cable from the square hole in the corner panel of the refrigerant piping section of the main unit.
- Feed the cable through the electric component box of the main unit as shown in the illustration, and then connect it to CN90 on the control board. Adjust the length of the cable so the corner panel can be removed, and then secure the cable with the clamp.

10.7. Check

- Make sure that there is no gap between the unit and the grille, or between the grille and the surface of the ceiling. If there is any gap between the unit and the grille, or between the grille and the surface of the ceiling, it may cause dew to collect.
- Make sure that the wires have been securely connected.

10.8. Installing the intake grille (Fig. 10-11)

When reinstalling the corner panels (each with a safety wire attached), connect the other end of each safety wire to the grille using a screw (4 pcs, 4×8) as shown in the illustration.

- * If the corner panels are not attached, they may fall off while the unit is operating.
 Perform the procedure that is described in "11.2. Preparing to attach the grille" in
- reverse order to install the intake grille and the corner panel.
- Multiple units can be installed with grille so that the position of the logo on each corner panel is consistent with the other units regardless of the orientation of the intake grille. Align the logo on the panel according to the wishes of the customer as shown in the diagram to the left. (The position of the grille can be changed.)
 - D Refrigerant piping of the main unit
 - Drain piping of the main unit
 - (F) Position of the corner panel when sent from the factory (logo attached). * Installation in any position is possible.
 - © Position of the levers on the intake grille when sent from the factory.
 - * Although the clips can be installed in any of four positions, the configuration shown here is recommended.

(It is not necessary to remove the intake grille when maintenance is performed on the electric component box of the main unit.)

H Receiver (Only PLP-6AALM Panel)

Please be sure to put the contact address/telephone number on this manual before handing it to the customer.



HEAD OFFICE: MITSUBISHI DENKI BLDG., 2-2-3, MARUNOUCHI, CHIYODA-KU, TOKYO 100-8310, JAPAN