

Function compability list of PZ-62DR-E when it is connected to LGH-RVX-E or LGH-RVXT-E series

○ : available, △ : limited, × : not available

PZ-62DR-E menu	With LGH-RVX or LGH-RVXTseries	Remarks
Main menu	-	-
User option	-	-
Fan speed timer	○	-
Timer	○	-
Weekly timer	○	Day of the week and time that Night-purge start and stop are set in Night-purge setting menu.
Night-purge setting	△	when the value of Function setting No.30 is set from 0 (not available) to 1~4 (available, Fanspeed 1~4), it is possible to set day of the week and time that Night-purge start and stop in this menu.
Commissioning	-	-
Initial setting	-	-
Main / Sub	○	-
Clock	○	-
Contrast	○	-
Display details	△	•Display of CO ₂ concentration is not available. •Outdoor, Return and Supply temperatures can be displayed.
Administrator password	○	Password in moving to Commissioning menu can be changed. As for Factory setting password, please refer to Instruction Book.
Language selection	○	Supported languages are different by models.
Airflow	×	Not available
Auto bypass	×	Not available Same function can be set in Function setting No.52~54. As for details, please refer to Instruction Book.
External input	-	-
CO2 control	×	Not available
Service	-	-
Input maintenance info	-	-
Model name input	○	-
Serial No. input		
Dealer Tel input		
Initialize maintenance info.	○	-
Function setting	○	-
Initializing	○	-
Restriction	○	-
Error information	○	-
Error history	○	-
Run time	×	Not available
Maintenance interval	×	Not available
Maintenance	○	-