Back to Index page

C.4 OPTIONAL PARTS

C.4.1 AIR CLEANING FILTER C-491
C.4.1.1 Wall-mounted Type C-491
C.4.1.2 Floor and Ceiling Type C-491
C.4.2 DEODORIZING FILTER C-492
C.4.2.1 Wall-mounted Type C-492
C.4.2.2 Floor and Ceiling Type C-492
C.4.3 REMOTE CONTROLLER HOLDER C-493
C.4.3.1 Wall-mounted Type C-493
C.4.4 QUICK CLEAN KIT C-493
C.4.4.1 Wall-mounted Type C-493
C.4.5 OPTIONAL PARTS FOR MULTI SYSTEMS C-494
C.4.5.1 Different-diameter pipe C-494
C.4.5.2 Outlet guide C-494

C.4.1 AIR CLEANING FILTER

C.4.1.1 Wall-mounted Type

- AIR CLEANING FILTER removes fine dust of 0.01 micron from air by means of static electricity.
- Normal life of AIR CLEANING FILTER is 4 months. However, when it becomes dirty, replace it as soon as possible.
- Clogged AIR CLEANING FILTER may reduce the air conditioner capacity or cause frost on the air outlet.
- DO NOT reuse AIR CLEANING FILTER even if it is washed.
- DO NOT remove or attach AIR CLEANING FILTER during unit operation.

Model	Part No.	Model	Part No.	Model	Part No.
MS-A18WV MS-A24WV MS-A30WV	MAC-1700FT	MSH-A18WV MSH-A24WV MSH-A30WV	MAC-1700FT	MSZ-A09YV MSZ-A12YV	MAC-1300FT
MS-AXV07WV MS-AXV09WV MS-AXV12WV MSC-A07YV MSC-A09YV MSC-A12YV	MAC-1300FT	MSH-AXV07WV MSH-AXV09WV MSH-AXV12WV	MAC-1300FT	MSZ-A18YV MSZ-A24YV MSZ-A26YV	MAC-1700FT



C.4.1.2 Floor and Ceiling Type

- If the air cleaning filter is clogged, it may lower the unit's capacity or cause condensation at the air outlet .
- The air cleaning filter is disposable . The standard usable term is about 4 months . However , if the color of the filte turns to dark brown , replace soon .



Model	Part No.
MCF-A12WV MCF-A18WV MCF-A24WV MCFH-A12WV MCFH-A18WV MCFH-A24WV MCFZ-A12WV MCFZ-A18WV MCFZ-A24WV	MAC-1200FT

C.4.2 DEODORIZING FILTER

C.4.2.1 Wall-mounted Type

- DEODORIZING FILTER removes ammonia and hydrogen sulphide emitted from tobacco, and odor of pets.
- Clean DEODORIZING FILTER every two weeks. If the filter is particularly dirty, clean the filter more often.
- For cleaning, soak the filter in warm water for a while, and then wash and rinse it. Dry the filter in the shade thoroughly.
- When the filter color is still dark even after cleaning, replace the filter with a new one.
  Replace the filter at least once a year.

Model	Part No.
MS-AXV07WV MS-AXV09WV MS-AXV12WV MSH-AXV07WV MSH-AXV09WV MSH-AXV12WV	MAC-1800DF



Deodorizing filter (Gray sponge type)

- DEODORIZING FILTER and AIR CLEANING FILTER can be attached on either side.

C.4.2.2 Floor and Ceiling Type

- Clean the filter every two weeks . When it becomes too dirt , clean it more often .
- Replace the filter with a new one when its color can not be restored even after washing or when the filter becomes dark.
- Standard interval for the filter replacement is about 1 year .



Model	Part No.
MCF-A12WV MCF-A18WV MCF-A24WV MCFH-A12WV MCFH-A18WV MCFH-A24WV MCFZ-A12WV MCFZ-A18WV MCFZ-A24WV	MAC-1700DF

C.4.3 REMOTE CONTROLLER HOLDER

C.4.3.1 Wall-mounted Type

Model	Part No.
MS-AXV07WV MS-AXV09WV MS-AXV12WV MSH-AXV07WV MSH-AXV09WV MSH-AXV12WV	MAC-1200RC



C.4.4 QUICK CLEAN KIT

C.4.4.1 Wall-mounted Type

● You can sweep the surface of heat exchanger if you install the special-made brush to your vacuum cleaner.

Model	Part No.	
MSZ-A09YV MSZ-A12YV	MAC-093SS-E	



C.4.5 OPTIONAL PARTS FOR MULTI SYSTEMS

C.4.5.1 Different-diameter pipe

MXZ-A18WV	Model name	Connected pipes diameter (mm)	Length A	Length B	Length C
For different-diameter pipes	MAC-A454JP	ϕ9.52 — ϕ12.7 (3/8) (1/2)	ϕ9.52 (3/8)	ϕ12.7 (1/2)	69

Unit : mm (inch)



MXZ-A26WV MXZ-A32WV	Model name	Connected pipes diameter (mm)	Length A	Length B	Length C
For different-diameter pipes	MAC-A454JP	ϕ9.52 — ϕ12.7 (3/8) (1/2)	ϕ9.52 (3/8)	ϕ12.7 (1/2)	69
	MAC-A455JP	ϕ12.7 — ϕ9.52 (1/2) (3/8)	ϕ12.7 (1/2)	ϕ9.52 (3/8)	65
	MAC-A456JP	ϕ12.7 — ϕ15.88 (1/2) (5/8)	ϕ12.7 (1/2)	ϕ15.88 (5/8)	66.5

C.4.5.2 Outlet guide

Changes air discharge direction.

Applied unit	Model name	Model code
MXZ-A26WV MXZ-A32WV	MAC-855SG	51H-855